

Weaver's Candle stick


Stock 3/8"x 14" sq Mild Steel



2. Bend the flattened portion 90° to the shaft










5. Draw a taper on the unworked end and form a hock at 90° to the other end, so that the candle will clear its hanging surface.



Originally designed to hang on the end of the loom so the weavers could work after dark.

FWilson